



# DPDK performance Lessons learned in vRouter

Stephen Hemminger stephen@networkplumber.org @networkplumber

#### Architecture



## Lcore Assignment



#### Internal Instrumentation


Dataplane CPU activity

Core	Interface	RX Rate	TX Rate	Idle
1	p1p1	14.9M		0
2	p1p1	0		250
3	p33p1	0		250
4	p33p1	1		250
5	p1p1		0	250
6	p33p1		11.9M	1

### Idle sleep

- 100% Poll → 100% CPU
  - CPU power limits
  - No Turbo boost
  - PCI bus overhead
- Small sleep's
  - 0 250us
  - Based on activity

#### Link state



- TAP device created by dataplane
- LINK UP/DOWN
  - When change
  - 5sec interval
  - Updates statistics
  - Acts as keepalive

## Slowpath

- Packets placed in DPDK rte\_ring
  - Wakeup via eventfd
- Shadow thread
  - Poll's for event or kernel packets
- Packet's received
  - Sent to kernel via TAP device
- Local packets
  - injected into Tx Thread

#### Perf – active thread

```
Samples: 16K of event 'cycles', Event count (approx.): 11763536471
14.93%
        dataplane [.] ip_input
10.04%
        dataplane [.] ixgbe xmit pkts
 7.69%
        dataplane [.] ixqbe recv pkts
 7.05%
        dataplane [.] T.240
 6.82%
        dataplane [.] fw action in
 6.61%
        dataplane [.] fifo enqueue
                  [.] flow action_fw
 6.44%
        dataplane
 6.35%
        dataplane [.] fw action out
 3.92%
        dataplane
                   [.] ip hash
 3.69%
        dataplane [.] cds lfht lookup
 2.45%
                  [.] send packet
        dataplane
 2.45%
        dataplane [.] bit reverse ulong
```

#### Performance rules

- No syscall's
- No mutex's
- Avoid using spinlock
- Real-time SCH\_FIFO

#### TSC counter

```
CPU stall
while(1)
  cur tsc = rte rdtsc();
  diff tsc = cur tsc - prev tsc;
  if (unlikely(diff tsc > drain tsc)) {
     for (portid = 0; portid < RTE MAX ETHPORTS;
portid++) {
        send burst(qconf,
             qconf->tx mbufs[portid].len,
             portid);
```

Heisenburg: observing performance slows it down

```
fw_action_in
```

```
struct ip fw args fw args = {
                   m = m
                   .client = client,
                   .oif = NULL };
1.54 | 1d:
          movzbl %sil,%esi
0.34
            mov %rsp,%rdi
0.04
            mov $0x13, ecx
0.16
                  %eax, %eax
            XOY
57.66
            rep stos %rax, %es: (%rdi)
4.68
                   %esi,0x90(%rsp)
            mov
20.45
            mov %r9,(%rsp)
```

## Why is QoS slow?

```
static inline void
rte sched port time resync(struct rte sched port *port)
{
     uint64 t cycles = rte get tsc cycles();
     uint64 t cycles diff = cycles - port->time cpu cycles;
     double bytes diff = ((double) cycles diff) /
                         port->cycles per byte;
     /* Advance port time */
     port->time cpu cycles = cycles;
     port->time cpu bytes += (uint64 t) bytes diff;
```

#### Mutual Exclusion


#### Locking

- Reader/Writer lock is expensive
- Read lock has more overhead than spin lock
- Posix locks even more expensive

#### Userspace RCU

- Don't modify, create and destroy
- Impacts thread model

## Longest Prefix Match



#### LPM issues

- Prefix → 8 bit next hop
- Missing barriers
- Rule update
- Fixed size /8 table

Q & A

## Thank you

Stephen Hemminger stephen@networkplumber.org @networkplumber